Fire-Cryer® Plus Voice Enhanced Sounder Installation Instructions



WIRING AND SWITCH DETAILS

Unique serial number label



Installation:

Sounder unit is fitted to base with the two screws supplied.

DIL switch for message and volume setting.

Switch ↑ UP-ON

Volume Settings	SW1	SW2		
0db (Max Volume)	OFF	ON		
-6dB	OFF	OFF		
-12dB	ON	ON		
-18dB (Min Volume)	ON	OFF		
Strobe (Iffitted)	SW3			
Normal Output	OFF			
High Output	ON			
Message Selection*	SW4	SW5	SW6	SW7
Message Selection* Multi-Message Use	SW4	SW5	SW6	SW7
- u				
Multi-Message Use	OFF	OFF	OFF	OFF
Multi-Message Use Message 1	OFF ON	OFF OFF	OFF OFF	OFF OFF
Multi-Message Use Message 1 Message 2	OFF ON OFF	OFF OFF ON	OFF OFF	OFF OFF
Multi-Message Use Message 1 Message 2 Message 3	OFF ON OFF	OFF OFF ON	OFF OFF OFF	OFF OFF OFF

Note: SW8 is not used.

Message 7

*Message Selection:

For use in Multi-Message Mode with the MMSP (Multi-Message Switching PCB) select 'Multi Message Use' from the table above.


ON

ON

ON OFF

For Single Message Mode, use the table above to select one of the pre-stored messages - see overleaf for message list.

PLUS PRODUCTS



Vimpex Limited

Star Lane, Great Wakering Essex SS3 0PJ England Tel: +44 (0) 1702 216999 Fax: +44 (0) 1702 216699 E-mail: sales@vimpex.co.uk www.vimpex.co.uk



Part No: IS/FC3/3VM4009M

Fire-Cryer® Plus Voice Enhanced Sounder Installation Instructions



MESSAGE LIST

The Standard Message Set consists of 7 pre-programmed messages with tones (See Table A).

When used as a Multi Message Sounder the Multi Message Switching PCB will assign the messages to the following

Table A					triggers:		
	Starting Tone See table below†	Two Letter Message Code	Beacon Flashes*	Message Content			
Message 1	1		Υ	Attention, attention. Fire has been detected in this area	S1A/ S1B		
Message 2	2	AB	Υ	Attention, attention. The secure perimeter at lower ground level has been compromised. Please send staff to investigate. Compromised. Please send staff to investigate.	MA		
Message 3	2	MA		Attention. Attention. The adjacent ward is evacuating their area. Compromised.	МВ		
Message 4	0	AD	N	This is a fire alarm test. No action required. No action required.	МС		
Message 5	0	SP	N	Fire alert, fire alert. Would all available staff report to the ward office immediately	MD		
Message 6	3	СС	N	Fire alert, fire alert. Would all available staff report to reception immediately	ME		
Message 7	1	AF	Υ	Attention. Attention. There is a fire alarm activation in this building	MF		

^{*}If Fitted

_ .. .

